






Model Number

NCN3-F25-N4-V1

Features

- For installation in housing
- Direct mounting on standard actuators
- Satisfies machinery directive
- **EC-Type Examination Certificate** TÜV99 ATEX 1479X

Connection



Accessories

BT32

Activator for F25 series

BT32XS

Activator for F25 series

BT32XAS

Activator for F25 series

BT33

Activator for F25 series **BT34**


Activator for F25 series

V1-G

4-pin, M12 female field-attachable connector

V1-G-N4-5M-PUR Female cordset, M12, 4-pin, NAMUR, PUR cable

Dimensions



Technical Data

General	specifications	ŝ
---------	----------------	---

	-					
	Switching element function		DC	Dual NC		
	Rated operating distance	s _n	3 mm			
	Installation		embeddable mountable			
	Output polarity		NAMUR			
	Assured operating distance	sa	0 2.43	3 mm		
	Reduction factor r _{Al}		0.5			
	Reduction factor r _{Cu}		0.45			
	Reduction factor r ₃₀₃		1			
	Reduction factor r _{St37}		1.1			
	Reduction factor r _{Brass}		0.63			
N	Nominal ratings					

Uo Nominal voltage 8.2 V (R_i approx. 1 kΩ)

Switching frequency 0 ... 1500 Hz Hysteresis Н typ. 5 %

reverse polarity protected Reverse polarity protected

Short-circuit protection Suitable for 2:1 technology yes , Reverse polarity protection diode not required

Current consumption Measuring plate not detected ≥ 3 mA

Measuring plate detected Indication of the switching state ≤ 1 mA LED, yellow

Ambient conditions

Ambient temperature -25 ... 100 °C (-13 ... 212 °F) -40 ... 100 °C (-40 ... 212 °F) Storage temperature

Mechanical specifications Connection type Device connector M12 x 1, 4-pin Housing material

Sensing face PRT IP67 Protection degree

Tightening torque, fastening screws M5 x 25 : 2.7 Nm Mounted on mechanical drive

General information

Use in the hazardous area see instruction manuals 1G; 2G; 3G; 3D Category

Compliance with standards and directives

Standard conformity

EN 60947-5-6:2000 NAMUR IEC 60947-5-6:1999 NE 21:2007

Electromagnetic compatibility FN 60947-5-2:2007 Standards IEC 60947-5-2:2007

Approvals and certificates

FM approval

Control drawing 116-0165F **UL** approval cULus Listed, General Purpose cCSAus Listed, General Purpose CSA approval

CCC approval Products with a maximum operating voltage of ≤36 V do not bear a CCC marking because they do not require approval.

ATEX 1G

Instruction

Device category 1G

Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate

Appropriate type

Effective internal capacitance Ci

Effective internal inductance La

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Special conditions

Protection from mechanical danger

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2006, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety"

Use is restricted to the following stated conditions

C€0102

⟨ы⟩ II 1G Ex ia IIC T6

TÜV 99 ATEX 1479 X

NCN3-F25.-N4...

 \leq 100 nF A cable length of 10 m is considered.

The value is applicable for the sensor circuit.

 \leq 100 μ H A cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed. The special conditions

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions.

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.

PEPPERL+FUCHS

ATEX 2G

Instruction

Device category 2G

Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type

Effective internal capacitance Ci

Effective internal inductance Li

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Special conditions

Protection from mechanical danger

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2006, EN 60079-11:2007 Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions **C**€0102

⟨Ex⟩ II 1G Ex ia IIC T6

TÜV 99 ATEX 1479 X

NCN3-F25.-N4...

≤ 100 nF; a cable length of 10 m is considered. The value is applicable for the sensor circuit.

 \leq 100 μH ; a cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to

be observed. The special conditions must be adhered to!
Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

www.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com

ATEX 3D Note

This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

for use in hazardous areas with non-conducting combustible dust Device category 3D

Directive conformity 94/9/EG EN 50281-1-1 Standard conformity Protection via housing

Use is restricted to the following stated conditions

CE symbol **C** €0102

Ex-identification ⟨ II 3D IP67 T 111 °C (231.8 °F) X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. Each sensor circuit van

be operated with the stated maximum values.

No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Special conditions

Plug connector

Minimum series resistance R_V

Maintenance

Installation, Comissioning

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances Maximum operating voltage U_{Bmax}

are not permitted.

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series Maximum heating (Temperature rise)

resistance Rv.

at U_Bmax=9 V, R_V=562 Ω 11 K

using an amplifier in accordance with 11 K EN 60947-5-6

The plug connector must not be disconnected under voltage. The proximity switch is marked as follows: "DO NOT DISCON-NECT UNDER VOLTAGE!" When the plug connector is disconnected the ingress of dirt into the inner areas (i.e. the areas,

which are not accessible in the plugged-in condition) must be prevented.

The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting

accessory from Pepperl + Fuchs).

Protection from mechanical danger

The sensor must not be mechanically damaged.

ATEX 3D (tD)

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with non-conducting combustible dust

Directive conformity 94/9/EG

EN 61241-0:2006, EN 61241-1:2004 Standard conformity

Protection via housing "tD"

Use is restricted to the following stated conditions

CE symbol (€

Ex-identification ⟨Ex⟩ II 3D Ex tD A22 IP67 T80°C X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. Each sensor circuit van Installation, Comissioning

be operated with the stated maximum values.

Maintenance No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Special conditions

Minimum series resistance R_V A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance

with the following list. This can also be assured by using a switch amplifier.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

Maximum permissible ambient tempera-

ture T_{Umax}

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.

at U_{Bmax}=9 V, R_V=562 Ω 59 °C (138.2 °F) using an amplifier in accordance with $\,$ 59 °C (138.2 °F) EN 60947-5-6

Plug connector

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented.(i.e. the area that is inaccessible when the connector is inserted)

The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting

accessory from Pepperl + Fuchs).

Protection from mechanical danger

The sensor must not be exposed to ANY FORM of mechanical danger.

Protection from UV light

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

www.pepperl-fuchs.com

ATEX 3G (nL)

Instruction

Device category 3G (nL)

Directive conformity Standard conformity

CE symbol

Ex-identification

Effective internal capacitance C

Effective internal inductance L

General

Installation, Comissioning

Maintenance

Special conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V

for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW Ji=25 mA T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW. Ii=52 mA. T5 for Pi=169 mW, Ii=52 mA, T4-T1 Protection from mechanical danger

Protection from UV light

Connection parts

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/FG

EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions €0102

II 3G Ex nL IIC T6 X

 \leq 100 nF ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.

 \leq 100 μH ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Directive 94/9EG is generally applicable only to the use of electrical apparatus operating at atmospheric conditions

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group complies with the connected, supplying, power limiting circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Each sensor circuit van be operated with the stated maximum values.

64 °C (147.2 °F) 64 °C (147.2 °F) 64 °C (147.2 °F) 59 °C (138.2 °F) 59 °C (138.2 °F) 59 °C (138.2 °F) 41 °C (105.8 °F) 41 °C (105.8 °F)

The sensor must not be exposed to ANY FORM of mechanical danger. When used in the temperature range below -20 $^{\circ}$ C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

FPEPPERL+FUCHS

ATEX 3G (ic)

Instruction

Device category 3G (ic)

Directive conformity Standard conformity

CE symbol

Ex-identification

Effective internal capacitance Ci

Effective internal inductance Li

General

Installation, Comissioning

Maintenance

Special conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V

for Pi=34 mW Ji=25 mA T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW. Ii=25 mA. T5 for Pi=64 mW. Ii=25 mA. T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 Protection from mechanical danger

Connection parts

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

EN 60079-11:2007 Ignition protection category "ic" Use is restricted to the following stated conditions $C \in \Gamma$

⟨Ex⟩ II 3G Ex ic IIC T6 X

≤ 100 nF; a cable length of 10 m is considered. The value is applicable for the sensor circuit.

 \leq 100 μH ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Directive 94/9EG is generally applicable only to the use of electrical apparatus operating at atmospheric conditions.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group depends on the connected and energy-limited supply circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Each sensor circuit van be operated with the stated maximum values.

64 °C (147.2 °F) 64 °C (147.2 °F) 64 °C (147.2 °F) 59 °C (138.2 °F) 59 °C (138.2 °F) 59 °C (138.2 °F) 41 °C (105.8 °F) 41 °C (105.8 °F) 41 °C (105.8 °F)

The sensor must not be mechanically damaged. When used in the temperature range below -20 $^{\circ}\mathrm{C}$ the sensor should be protected from knocks by the provision of an additional housing.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Pepperl+Fuchs Group

www.pepperl-fuchs.com